




# **PARTS CATALOG**

**BRUSHCUTTER  
740 T**



# Engine




## Engine

---

Reference	Qty	Item number	Description
1	1	074000208	Cover
2	1	61052008R	Screw
3	3	3801010R	Screw
4	2	3916005R	Washer
5	1	072700036A	Grommet
6	2	004000015R	Piston ring d.40
7	1	3055115	Spark plug
8	1	074000280A	Cylinder
9	1	074000268R	Crankshaft
10	2	074000267AR	Washer
11	1	072700046R	Bearing
12	1	3028013R	Key
13	4	094000101R	Screw
14	4	3833073	Washer
15	1	074000279A	Piston assy Ø40
16	2	3819006	Washer
17	2	094000099R	Seal ring
18	2	3023008R	Plug
19	1	074000204	Crankcase assy
20	2	094000006R	Bearing
21	2	3918010R	Washer
22	2	3806026AR	Screw
23	1	4095211R	Plate
24	1	074000206AR	Muffler
25	1	074000013A	Gasket
26	1	4120070	Washer
27	1	3960017AR	Screw
28	1	074000207	Muffler cover
29	1	074000156A	Gasket set
30	2	093000167	Ring
31	1	074000014R	Piston pin
32	1	61110034	Hose
33	1	072700076A	Gasket
34	1	074000130C	Insulator
35	1	072700077AR	Gasket
36	1	074000397	Carburetor kit C1Q-E10
37	2	3801047	Screw
38	1	072700458	Shutter
39	2	074000391	Starter lever
40	1	320000004	Screw
41	1	4120070	Washer
42	1	072700460	Guard
43	1	074000390R	Filter support
44	1	072700461BR	Air filter
45	1	072700457A	Filter cover
46	1	61052009B	Screw

# Engine




## Engine

---

Reference	Qty	Item number	Description
47	1	072700075A	Gasket
48	1	61070006	Gasket
49	1	61070011A	Breather valve
50	1	61070079R	Tank cap
51	1	4196102	Hose
52	1	094600450R	Fuel filter
53	1	072700467BR	Tank
54	1	4196020	Spacer
55	1	072700454A	Stand
56	3	3918005	Washer
57	3	3819006	Washer
58	2	3801013R	Screw
59	1	3801017R	Screw
60	1	074000278	Shaft+piston Ø40
61	1	3801008	Screw
62	1	072700543R	Air filter
63	4	3801040R	Screw

# Starter assy and clutch












## Starter assy and clutch

---

Reference	Qty	Item number	Description
1	1	3912009	Nut
2	4	61052008R	Screw
3	1	004000132R	Spring
4	1	4098073R	Starter rope
5	1	072700085BR	Pulley
6	1	094600041AR	Screw
7	1	3918005	Washer
8	1	072700089	Bushing
9	1	093500397	Starter handle
10	1	006000829	Washer
11	1	072700468AR	Starter assy
12	1	072700235	Nut
13	1	005000361	Washer
14	2	072700087	Pawl
15	2	072700088R	Spring
16	2	3026004	Ring
17	1	072700466	Clutch driver
18	1	074000378R	Flywheel
19	1	3818011A	Washer
20	1	3916010	Washer
21	1	072700072	Support
22	1	3801010R	Screw
23	1	094600169	Spring
24	1	094600097A	Spark plug cap
25	1	072700391R	Ignition coil
26	1	4179087A	Cable
27	2	006000064	Screw
28	2	3833073	Washer
29	1	3801022	Screw
30	1	074000244A	Sleeve
31	1	074000212R	Cover
32	4	3801011	Screw
33	4	072700189	Washer
34	1	074000027	AV-mount
35	1	074000030	Ring
36	1	3024015	Ring
37	1	4191153AR	Clutch
38	1	072700472AR	Starter case
39	4	61052005	Screw
40	1	3035019R	Bearing
41	1	3025022	Ring
42	1	4191030R	Clutch drum
43	1	4191028R	Spring
44	2	072700188	Washer
45	2	4191027ER	Pin

# Transmission














## Transmission

---

Reference	Qty	Item number	Description
1	1	61042049	Support assy
2	1	61040154	Absorber case assy
4	4	61040110R	Clamp
5	5	3914003	Nut
6	1	2317021R	Switch
7	2	61040111	Sleeve
8	1	61040112	Support
9	1	3980011	Nut
10	1	66030012	Washer
11	3	3801016	Screw
12	1	61040136	Hub
13	1	61040044	Spring
14	1	61040135	Hub
15	1	61042030	Knob
16	1	4191192R	Tube Ø28
17	1	4098116R	Drive shaft
18	1	61040140R	Knob
19	1	61040131R	Handle
20	2	3960029	Screw
21	1	4138361R	Spring
22	1	4174245CR	Throttle lever
23	1	4174246AR	Lever
24	1	4138360R	Spring
25	1	4138358R	Button
26	1	074000296	Cable
27	1	61040040BR	Handlebar
28	1	4100098BR	Spring
29	1	4138359R	Button
30	1	3960021	Screw
31	1	61052059R	Handlebar
32	1	61040074AR	Screw
33	1	4100456R	Guard
34	1	4179089R	Flange
35	1	3025019	Ring
36	1	3024010R	Ring
37	1	3035040R	Bearing
38	1	3035040R	Bearing
39	1	3025009	Ring
40	1	4138311A	Ring
41	1	61040144R	Gear case
42	1	61040071R	Cap
43	1	3901016	Screw
44	1	3034218	Bearing
45	1	61040106A	Pin
46	1	3034012R	Bearing
47	1	3025022	Ring

# Transmission





## Transmission

---

Reference	Qty	Item number	Description
48	1	3050018R	Seal ring
49	1	61040066	Spacer
50	1	61040145R	Hub
51	1	61042032BR	Bevel gear Ø28
52	1	61040133	Bevel gear set
53	1	3901008	Screw
54	1	3960071	Screw
55	1	3801016	Screw
56	1	074000301	Throttle cable
57	1	074000183R	Clamp
58	1	61250066R	Bevel gear Ø28
59	1	61250054R	Pin
60	1	61110074R	Guard
61	1	61110075R	Nut
62	2	074000035R	AV-mount
63	1	4175150A	Bevel gear set

# Carburetor C1Q-E10





## Carburetor C1Q-E10

---

Reference	Qty	Item number	Description
1	2	2318542	Screw
2	1	074000147	Cover
3	1	074000150	Repair kit
4	1	074000238	Cover
5	1	074000151	Diaphragm set
6	1	2318572	Primer pump
7	1	095000164	Ring
8	1	074000397	Carburetor kit C1Q-E10
9	1	2318592	Valve
10	1	2318191	Cover
11	4	035000162	Screw
12	1	093500115	Spring
13	1	074000143	Screw H
14	1	093500269	Screw L
15	1	035000165	Spring
16	1	072700214	Spring
17	1	072700209	Shaft
18	1	2318211	Pin
19	1	003300209	Screw
20	1	072700211	Shutter
21	1	094600148	Spring
22	1	074000240	Adjust.screw
24	2	2318521	Screw
25	1	2318526	Cover
26	1	2318875	Pump
27	1	2318874	Cover
28	1	2318872	Shutter
29	1	2318388	Screw
30	1	2318412	Hooking spring
31	1	2318387	Ring
32	1	2318871	Shaft
33	1	2318528	Spring
34	1	2318532	Spring
35	1	2318882	Screw L
36	1	2318881	Screw H
37	1	2318886	Repair kit
38	1	2318885	Diaphragm set
39	1	2318880	Cover
40	4	2318522	Screw
41	1	2318392	Filter
42	1	2318535	Ring
43	1	2318527	Screw
45	1	003300201	Spindle
46	1	003300202	Screw
47	2	2318876	Screw

# Euro1 carburettor WT-460B



DA NOVEMBRE  
 FROM NOVEMBER  
 AB NOVEMBER  
 DESDE NOVIEMBRE  
 DEPUIS NOVEMBRE

2004

● KIT MEMBRANE & GUARNIZIONI  
 5 DIAPHRAGM & GASKET SET










■ KIT RIPARAZIONE  
 3 REPAIR KIT

## Euro1 carburettor WT-460B

---

Reference	Qty	Item number	Description
1	1	074000239	Screw
2	1	074000147	Cover
3	1	074000150	Repair kit
4	1	074000238	Cover
5	1	074000151	Diaphragm set
6	1	2318572	Primer pump
7	1	095000164	Ring
8	1	003300201	Spindle
9	1	2318592	Valve
10	1	2318191	Cover
11	2	035000162	Screw
12	1	093500115	Spring
13	1	2318699	Screw H
14	1	2318698	Screw L
15	1	2318880	Cover
16	4	072700347	Spring
17	1	072700209	Shaft
18	1	2318211	Pin
19	1	003300209	Screw
20	1	072700211	Shutter
21	1	094600148	Spring
22	1	074000240	Adjust.screw
23	1	2318694	Cap
24	1	003300202	Screw
25	1	2318695	Cap
26	1	074000391	Starter lever
27	1	2318690R	Carburetor WT-460B

# Accessories





## Accessories

---

Reference	Qty	Item number	Description
1	1	4199039AR	Compl. nylon head Ø3
2	1	3960040R	Screw
3	1	4174278	Plate
4	4	3802004CR	Screw
5	1	4174283A	Skirt w/blade
6	1	4174275R	Blade
7	1	61042011A	Guard assy
8	2	4199005A	Bushing
9	1	4199008B	Insert
10	1	4199004	Spring
11	1	4199031A	Nylon spool Ø3
12	1	4199026B	Cover
13	1	4199046	Cover
14	1	61052031	Tool kit
15	1	4179164R	Harness
16	1	074000328	Labels kit
17	1	61112059A	Compl. nylon head Ø3
18	1	4095673AR	Disk
19	1	63019010A	Quick load nylon head Ø3
20	1	4199048R	Spring
21	1	4199049	Nylon spool
22	1	61110076	Insert
23	1	63050016	Hooking spring
24	1	63019012A	Quick load nylon head Ø3